
Plastic Bearing

## **Oiles Hiplast N Flange Bushings**









Specify Part No. by required I.D. and length. (e.g.) I.D. is 8mm and length is 8mm.

## **HPF - 0808**

## Parts No.



\*\*The joint causes no influences upon rotation of the shaft. Be careful when press-fitting so that the joint is not at the position to which the maximum load is applied.



Shaft		I.D.	0.D.	FInage	Thick	kness	Length <b>ℓ</b> Tolerance ±0.3							I.D. tolerance
Size	Tolerance	φd	φD	φF	t	Tolerance	5	6	8	10	12	15	20	after press fitting (reference)
4	-0.040 -0.055	4	5	8	0.5	±0.05	0405							+0.112 -0.100
5	-0.040 -0.055	5	6	10	0.5	±0.02	0505			0510				+0.055 -0.040
6	-0.040 -0.055	6	7	11	0.5	±0.02		0606		0610				+0.055 -0.040
8	-0.040 -0.055	8	9	13	0.5	±0.02			0808			0815		+0.055 -0.040
10	-0.040 -0.058	10	11	16	0.5	±0.02				1010		1015		+0.058 -0.040
12	-0.040 -0.058	12	13	18	0.5	±0.02					1212		1220	+0.058 -0.040
15	-0.040 -0.058	15	16	22	0.5	±0.02						1515	1520	+0.058 -0.040

 $<sup>\</sup>mbox{\@scalebox{\@s$ 

<sup>\*\*</sup>The I.D. tolerances after press fitting are the reference values measured in the condition where the bushings are inserted into the housings and in close contact with them.